

Steering Wheel control Interfaces for Parrot Car kits

25-101C

Parrot CK 3000 EVO Steering control Interface
For CAN bus based cars (and BMW K Bus)



The 25-101C Can interface replaces the Parrot button and enables you to control the CK3000 using the cars steering wheel buttons. For cars without Phone buttons the Mode button is used.

Alfa 159, Brera, Spider (07)
Audi, A3, A4(04>), A5 (07>), A6,(04>). TT(06>), Q5 & Q7
BMW 1, 3, 5, 6, X3, X5, X6 Z4
Chrysler 300c, Voyager (06>), PT Cruiser (06>) Sebring (07>
Citroen C2(04>), C3 (02>), C4 (07>), C5(05>), C6/C8 (07>) Berlingo (08>)
Dodge Caliber / Nitro (07>)
Fiat 500, Brava, (07>), Croma (05>), Doblo (09>), Ducato III(06>), Qubo(08>), Grande Punto (05>), Fiorino (07>), Punto EVO (09>), Scudo (07>)
Jeep Commander (05>), Grand Cherokee (06>), Patriot (07>)
Mercedes A (03>), B (03>), C(03-06) W204, CL(03>), CLK (03>) W209, CLS (04> C219), S (06>W221), SL (03>), SLK (03>), E (03> W211), ML (06>W163) R(06>W251), GL (06>), Sprinter/Vito (03>), Viano/Vaneo (03>)
Mini One, Cooper, Cooper S, Cabrio, Clubman (01>)
Vauxhall Astra (06-09), Vectra (06>), Corsa (06>), Signum (06> Meriva (06-09) Tigra (06>) Antara (07>) Vivaro
Peugeot 207, 307, 308, 407, 3008, 5008
Porsche Cayenne (06>)
Renault Clio (06>), Modus (06>) Espace (05>), Laguna, Safrane, Scenic (06>), Twingo (09>), Megane III (09>), Laguna III (09>) Fluence (10>)
Seat Alhambra (06>), Altea (04>), Toledo (05>), Ibiza (05>) Ibiza (08>) Leon
Skoda Octavia (04>), Superb (08>), Roomster (09>), Yeti (09>) Scout (10>)
VW Golf V, Golf Plus, Golf VI, Passat (04>), Touran (04>), Touareg (04>), Touareg (08>), Eos (06>), Tiguan (08>), Passat CC (08>), Polo 2010



For 25-101C Use special SOT leads with CAN break out cables:
10-536-SWC for Audi/ VW, 10-504-SWC for BMW, 10-534-SWC for Mercedes C, 10-537-SWC for Mercedes E Class, 10-535-SWC for Peugeot/Citroen

25-101R2

Parrot CK 3000 EVO Steering control Interface
For cars with resistive based steering controls



The 25-101C Can interface replaces the Parrot button and enables you to control the CK3000 using the cars steering wheel buttons. For cars without Phone buttons the Mode button is used.

Alfa 146, 147, 156 (04>), Gt & GTV (04>)
Chevrolet ,Captiva, Epica, Aveo (06>) Laccetti (07>) HHR (09>)
Citroen C Crosser (07>)
Fiat Sedici (06>)
Ford C Max, S Max, (06>), Focus (02>), Galaxy (06>), Mondeo (04>), Transit (07>), Fiesta (02-07) Fiesta (08>), Tourneo (07>) Kuga (08>)
Honda CRV (06>), Civic (06>) Jazz (09>), Insight (09) Accord (08>)
Hyundai Sante Fe (06>), i20, i30, IX35 (09>)
Kia Ceed, Soul
Mazda 2(04>) 3(03>), 5 (05>), 6 (02>) RX8 (07>), CX7 (06>)
Mitsubishi Outlander (07), Colt (09>),Pajero (06), Lancer (07>)
Vauxhall Agila (07>)
Peugeot 4007,
Ssangyong Actyon, Kyron, Rexton (06>), Rodius (08>),
Subaru Forrester(07>) Impreza (07-09), Legacy (07>) Tribeca (06>)
Suzuki Swift (05>),Grand Vitara (06>), Splash (07>) SX4 (06>)
Toyota Rav4 (04>), Corolla (04>), Avensis (04>),Yaris (04>) Auris (06>)
Landcruiser (07>) Prius (05>) Camry (04>), IQ (09>), Urban Cruiser

25-101CS for Parrot CK3000 EVO

GM LAN bus cars

The 25-101CS interface replaces the Parrot button and enables you to control the CK3000 using the cars steering wheel buttons.

Provides Ignition output to The Parrot kit



Chevrolet Cruise (09>) use with 10-580 cable

Saab 93 (06> 95 (06>) use with 10-557 or direct input 10-357

Vauxhall Insignia, Astra (10>) Meriva (10>) use with 10-580 cable



10-557 Saab SOT lead



10-580 Vauxhall SOT

25-200C

Parrot CK 3100 Steering control Interface
For CAN bus based cars (and BMW K Bus)

Alfa 159, Brera, Spider (07)

Audi, A3, A4(04>), A5 (07>), A6, (04>). TT(06>), Q5 & Q7

BMW 1, 3, 5, 6, X3, X5, X6 Z4

Chrysler 300c, Voyager (06>), PT Cruiser (06>) Sebring (07>

Citroen C2(04>), C3 (02>), C4 (07>), C5(05>), C6/C8 (07>) Berlingo (08>)

Dodge Caliber / Nitro (07>)

Fiat 500, Brava, (07>), Croma (05>), Doblo (09>), Ducato III(06>), Qubo(08>), Grande Punto (05>), Fiorino (07>), Punto EVO (09>), Scudo (07>)

Jeep Commander (05>), Grand Cherokee (06>), Patriot (07>)

Mercedes A (03>), B (03>), C (03-06) W204, CL(03>), CLK (03>) W209, CLS

(04> C219), S (06>W221), SL (03>), SLK (03>), E (03> W211), ML (06>W163)

R(06>W251), GL (06>), Sprinter/Vito (03>), Viano/Vaneo (03>)

Mini One, Cooper, Cooper S, Cabrio, Clubman (01>)

Vauxhall Astra (06-09), Vectra (06>), Corsa (06>), Signum (06> Meriva (06-

09) Tigra (06>) Antara (07>) Vivaro

Peugeot 207, 307, 308, 407, 3008, 5008

Porsche Cayenne (06>)

Renault Clio (06>), Modus (06>) Espace (05>), Laguna, Safrane, Scenic (06>), Twingo (09>), Megane III (09>), Laguna III (09>) Fluence (10>)

Seat Alhambra (06>), Altea (04>), Toledo (05>), Ibiza (05>) Ibiza (08>) Leon

Skoda Octavia (04>), Superb (08>), Roomster (09>), Yeti (09>) Scout (10>)

VW Golf V, Golf Plus, Golf VI, Passat (04>), Touran (04>), Touareg (04>),

Touareg (08>), Eos (06>), Tiguan (08>), Passat CC (08>), Polo 2010



The 25-200C Can interface enables you to control the CK3100 using the cars steering wheel buttons.

For cars without Phone buttons the Mode button is used.

Provides IGNITION OUTPUT to Parrot



For 25-200C Use special SOT leads with CAN break out cables:

10-536-SWC for Audi/ VW, 10-504-SWC for BMW, 10-534-SWC for Mercedes C, 10-537-SWC for Mercedes E Class, 10-535-SWC for Peugeot/Citroen

25-102 RADICAN

Parrot MKI Steering control Interface
For CAN bus based cars (and BMW K Bus)



The 25-102C Can interface replaces the Parrot Wireless remote button and enables you to control the MKI using the cars steering wheel buttons.
For cars without Phone buttons the Mode button is used.



Alfa 159, Brera, Spider (07)
Audi A3, A4(04>), A5 (07>), A6,(04>). TT(06>), Q5 & Q7
BMW 1, 3, 5, 6, X3, X5, X6 Z4
Chrysler 300c, Voyager (06>), PT Cruiser (06>) Sebring (07>
Citroen C2(04>), C3 (02>), C4 (07>), C5(05>), C6/C8 (07>) Berlingo (08>)
Dodge Caliber / Nitro (07>)
Fiat 500, Brava, (07>), Croma (05>), Doblo (09>), Ducato III(06>), Qubo(08>), Grande Punto (05>), Fiorino (07>), Punto EVO (09>), Scudo (07>)
Jeep Commander (05>), Grand Cherokee (06>), Patriot (07>)
Mercedes A (03>), B (03>), C(03-06) W204, CL(03>), CLK (03>) W209, CLS (04> C219), S (06>W221), SL (03>), SLK (03>), E (03> W211), ML (06>W163) R(06>W251), GL (06>), Sprinter/Vito (03>), Viano/Vaneo (03>)
Mini One, Cooper, Cooper S, Cabrio, Clubman (01>)
Vauxhall Astra (06-09), Vectra (06>), Corsa (06>), Signum (06> Meriva (06-09) Tigra (06>) Antara (07>) Vivaro
Peugeot 207, 307, 308, 407, 3008, 5008
Porsche Cayenne (06>)
Renault Clio (06>), Modus (06>) Espace (05>), Laguna, Safrane, Scenic (06>), Twingo (09>), Megane III (09>), Laguna III (09>) Fluence (10>)
Seat Alhambra (06>), Altea (04>), Toledo (05>), Ibiza (05>) Ibiza (08>) Leon
Skoda Octavia (04>), Superb (08>), Roomster (09>), Yeti (09>) Scout (10>)
VW Golf;f V, Golf Plus, Golf VI, Passat (04>), Touran (04>), Touareg (04>), Touareg (08>), Eos (06>), Tiguan (08>), Passat CC (08>), Polo 2010

10-504-MKICAN

Plug and play wire harness and Steering wheel interface kit
For Parrot MKI 9100 & 9200



BMW

10-534-MKICAN

Plug and play wire harness and Steering wheel interface kit
For Parrot MKI 9100 & 9200



MERCEDES

10-536-MKICAN

Plug and play wire harness and Steering wheel interface kit
For Parrot MKI 9100 & 9200



VW

and Audi cars with Quadlock



25-102L RADILAN

Parrot MKI Steering control interface
GM LAN bus cars

The 25-102L interface replaces the Parrot wireless remote and enables you to control the MKI using the cars steering wheel buttons.



Chevrolet Cruise (09>)
Saab 93 (06> 95 (06>)
Vauxhall Insignia, Astra (10>) Meriva (10>)



10-580-LAN

Plug and play wire harness

and For Parrot MKI 9100 & 9200

Vauxhall Insignia, Astra (10>) Meriva (10>)
Chevrolet Cruise (09>)



25-102R RADICOM

Parrot MKI Steering control Interface
For cars with resistive based steering controls

Alfa 146, 147, 156 (04>), Gt & GTV (04>)
Chevrolet ,Captiva, Epica, Aveo (06>) Laccetti (07>) HHR (09>)
Citroen C Crosser (07>)
Fiat Sedici (06>)
Ford C Max, S Max, (06>), Focus (02>), Galaxy (06>), Mondeo (04>),
Transit (07>), Fiesta (02-07) Fiesta (08>), Tourneo (07>) Kuga (08>)
Honda CRV (06>), Civic (06>) Jazz (09>), Insight (09) Accord (08>)
Hyundai Sante Fe (06>), i20, i30, IX55 (09>)
Kia Ceed, Soul
Mazda 2(04>) 3(03>), 5 (05>), 6 (02>) RX8 (07>), CX7 (06>)
Mitsubishi Outlander (07), Colt (09>),Pajero (06), Lancer (07>)
Vauxhall Agila (07>)
Peugeot 4007,
Ssangyong Actyon , Kyron, Rexton (06>), Rodius (08>),
Subaru Forrester(07>) Impreza (07-09), Legacy (07>) Tribeca (06>)
Suzuki Swift (05>),Grand Vitara (06>), Splash (07>) SX4 (06>)
Toyota Rav4 (04>), Corolla (04>), Avensis (04>),Yaris (04>) Auris (06>)
Landcruiser (07>) Prius (05>) Camry (04>), IQ (09>), Urban Cruiser

The 25-102R interface replaces the Parrot wireless remote control and enables you to control the MKI using the cars steering wheel buttons.

